


PLEASE READ: INFORMATION ABOUT YOUR NEW WATCH



MARCELLO C.
swiss made

OPERATING INSTRUCTIONS

Standard Automatic Models




Figure A

To set the time: (See Figure A)

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. Pull crown gently out to position 3. This will "hack" (stop) the second hand.
3. Turn crown to set hands in clockwise direction to desired time.
4. Push crown back in to position 1.
5. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

NOTE: Be careful not to cross-thread the crown or screw it down at an angle as this will damage the watch and affect the water resistance.

To set the date:

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. Pull crown gently out to position 2.
3. Turn crown clockwise until desired date appears in calendar window.
4. Push crown back in to position 1.
5. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

NOTE: Take AM/PM into account when setting time, so date changes at midnight, not at noon. It is recommended not to change the date with this quick-set function when the watch indicates time between 9.00 pm and 3.00 am.

To manually wind the automatic movement:

The motion of your arm during normal daily activities should be sufficient to keep the movement of your Marcello C. automatic timepiece wound. However, if you have not worn your watch for an extended period of time and the movement has stopped, you may need to manually wind it:

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. With crown in position 1, flush against the case, turn crown clockwise about 10-15 revolutions until you see the second hand moving again.
3. Reset time and date following instructions
4. Push crown back in to position 1.
5. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

Automatic GMT Models




Figure A

To set the time: (See Figure A)

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. Pull crown gently out to position 3. This will “hack” (stop) the second hand.
3. Turn crown to set hands in clockwise direction to desired time.
4. Push crown back in to position 1.
5. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

NOTE: Be careful not to cross-thread the crown or screw it down at an angle as this will damage the watch and affect the water resistance.

To set the date and GMT hand:

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. Pull crown gently out to position 2.
3. Turn crown counter-clockwise until desired date appears in calendar window.
4. Turn crown clockwise until desired 24h time is indicated by the GMT hand
(For example, a second time zone, indication of the time in 24h mode or GMT/UTC time).
5. Push crown back in to position 1.
6. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

NOTE: Take AM/PM into account when setting time, so date changes at midnight, not at noon. It is recommended not to change the date with this quick-set function when the watch indicates time between 9.00 pm and 3.00 am.

To manually wind the automatic movement:

The motion of your arm during normal daily activities should be sufficient to keep the movement of your Marcello C. automatic timepiece wound. However, if you have not worn your watch for an extended period of time and the movement has stopped, you may need to manually wind it:

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. With crown in position 1, flush against the case, turn crown clockwise about 10-15 revolutions until you see the second hand moving again.
3. Reset time and date following instructions
4. Push crown back in to position 1.
5. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

Standard Manual Wind Models




Figure A

To set the time: (See Figure A)

1. Pull crown gently out to position 2.
3. Turn crown to set hands in clockwise direction to desired time.
4. Push crown back in to position 1.

To manually wind the movement:

1. With crown in position 1, flush against the case, turn crown clockwise about 30-40 revolutions until you can feel a resistance indicating that the movement is fully wound. Please do not continue to wind the movement as this may damage the watch.

Chronograph Models




Figure A

To set the time: (See Figure A)

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. Pull crown gently out to position 3. This will "hack" (stop) the second hand at position **a**.
3. Turn crown to set hands in clockwise direction to desired time.
4. Push crown back in to position 1.
5. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

NOTE: Be careful not to cross-thread the crown or screw it down at an angle as this will damage the watch and affect the water resistance.

To set the date and day (if equipped):

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. Pull crown gently out to position 2.
3. Turn crown clockwise until desired date appears in calendar window.
4. Turn crown counter-clockwise until desired day appears in day window.
(German day wheel: MON = Monday, DIE = Tuesday, MIT = Wednesday, DON = Thursday, FRE = Friday, SAM = Saturday, SON = Sunday)
5. Push crown back in to position 1.
6. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

NOTE: Take AM/PM into account when setting time, so date changes at midnight, not at noon. It is recommended not to change the date with this quick-set function when the watch indicates time between 9.00 pm and 3.00 am.

To operate the Chronograph functions: (See Figure A)

1. Push the chronograph start/stop pusher at position **A**.
 2. This will start the chronograph and you will see the central chronograph second hand at position **b** as well as the 60 minute register at position **c** and the 12 hour register at position **d** to indicate elapsed time (seconds/minutes/hours).
 3. Push the chronograph start/stop pusher at position **A** to stop the chronograph and to restart it.
 4. Push the chronograph start/stop pusher at position **B** to reset the chronograph.
- Please always stop the chronograph by operating the start/stop pusher at position **A** before attempting to reset the chronograph.

To manually wind the automatic chronograph movement:

The motion of your arm during normal daily activities should be sufficient to keep the movement of your Marcello C. automatic timepiece wound. However, if you have not worn your watch for an extended period of time and the movement has stopped, you may need to manually wind it:

1. Turn crown counter-clockwise to unscrew it from the secured screwdown position.
(Please proceed directly to step 2 in case your watch is not equipped with a screw down crown)
2. With crown in position 1, flush against the case, turn crown clockwise about 10-15 revolutions until you see the second hand moving again.
3. Reset time and date following instructions
4. Push crown back in to position 1.
5. Turn crown clockwise while pushing gently towards the case until the threads catch and screw down the crown all the way and it is secured.

CARE AND MAINTENANCE

Your new Marcello C. watch has a mechanical movement which requires periodic maintenance to ensure optimal performance. Maintenance may include complete disassembly, cleaning, reassembly and lubrication of the delicate parts inside the mechanical movement, replacement of gaskets etc. A maintenance interval of 3 to 5 years is recommended and is in addition to more regular tests of the water resistance before the watch is exposed to any activities where it can be submerged in water or water can enter the case. Such a test should be performed regularly, at least annually before the summer season / bathing season to ensure integrity of the case, seals and gaskets. Never open the watch yourself! If your watch needs repair or adjustment, please contact your reseller or MarcelloC-watches.

WATER RESISTANCE

Marcello C. watches with water resistance ratings are tested at the factory to meet international standards for water resistance. Your Marcello C. watch will remain water resistant provided that the crown, pushers, crystal, case and gaskets remain intact. Therefore, periodic maintenance and tests are required. The gaskets and crown which seal the case are subject to wear and deterioration under normal use. These parts should be inspected and replaced as needed each time the watch is opened for service. We recommend you have the water resistance checked once a year by a service centre or agent, if possible before the bathing season.

















Activity Rating	Washing Hands	Shower Swimming	Snorkling Waterski	Scuba Diving
3 atm 30 m / 100 ft				
5 atm 50 m / 150 ft				
10 atm 100 m / 330 ft				
30 atm 300 m / 1000 ft				

Table: Water Resistance Rating and Activities

It is not recommended to wear a watch (even a diver watch) in e.g. a hot shower, sauna or hot tub as watches are not designed for this kind of use. The heat causes metal parts to expand at a different rate than the gaskets which consequentially might create small openings that can allow water or steam to penetrate the watch case.

CAUTION: Marcello C. will not be responsible for any damage caused by or related to leakage originating from improper handling or damage to the case, crown, gaskets or crystal or when the watch case has been opened other than by Marcello C. or an authorized service agent.

OBTAINING SERVICE

To obtain service for your Marcello C. watch, you should contact your dealer or MarcelloC-watches (for details on how to contact us, please see our website at www.marcelloc-watches.com).

Please do not send your watch directly to us unless you have contacted us and received an RMA number and instructions how to ship the watch. You may also send your watch to the manufacturer (Marcello C.) in Germany provided you have contacted them first and received instructions how to send it.

LIMITED WARRANTY INFORMATION

Congratulations on your purchase of a genuine Marcello C. wristwatch.

We appreciate the trust you have just placed in these timepieces. All watches sold by MarcelloC-watches are genuine and warranted to be free of defects in material and workmanship by the manufacturer (Marcello C.) for a period of two years from original date of purchase.

This warranty excludes damage or wear to the case including bezel and/or inlay, crystal, springbars, strap, bracelet and crown. This warranty pertains to normal use only and does not cover any damage due to accident, misuse, abuse, or negligence nor does it attend to products which have been repaired or altered by other than Marcello C. authorized service. No warranty is made or implied for timekeeping and accuracy of mechanical watches.

MARCELLO C. MANUFACTURERS WARRANTY

Marcello C. warrants their watches against defects in material and workmanship under normal use and service for two years from the original date of purchase. Marcello C., at their option, shall repair or replace the defective parts covered by this warranty. No consequential damages are covered.

This warranty does not cover any damage due to accident, misuse, abuse, or negligence nor does it attend to products that have been opened, repaired or serviced by other than Marcello C. authorized service. This warranty excludes damage or wear to the case including bezel and/or inlay, crystal, springbars, strap, bracelet and crown. The warranty pertains to normal use only and does not cover any damage due to accident, misuse, abuse, or negligence nor does it attend to products which have been altered.

This warranty is void if the timepiece was not purchased from an Authorized Marcello C. Dealer, as evidenced by a valid warranty card or proof of purchase. To be valid (for watches purchased from an authorized dealer in North America), the warranty card must show the name of the Authorized Marcello C. Reseller or Distributor (MarcelloC-watches), as well as been dated and signed by that dealer.

To obtain service under the Marcello C. Manufacturers Warranty, you will be required to present a valid warranty card and proof of purchase (sales receipt or invoice from an Authorized Marcello C. Reseller or MarcelloC-watches). To be valid, the warranty card must be properly filled out, dated and signed (for sales in North America) by an Authorized Marcello C. Reseller or by MarcelloC-watches.

MarcelloC-watches Return Policy

MarcelloC-watches takes pride in providing 1st class customer service and merchandise. Please inspect your new watch carefully upon receipt, but don't remove the protective stickers, remove the strap or bracelet, size the bracelet or wear the watch just yet until you are certain you will keep it. We accept returns **within** 3 days of customers receipt of product (you are expected to contact us within 3 days of receipt of the product (weekends or holidays included) and inform us of your intent, confirm the condition and request a RA# in case you want to take advantage of our return policy). MarcelloC-watches sells only brand new watches and the latest models. We cannot sell watches that have been worn or are out of style. Therefore we have set a fair yet **firm** policy regarding returns.

WATCHES MUST BE RETURNED IN BRAND NEW CONDITION. UNTIL YOU ARE SURE YOU WILL BE KEEPING THE WATCH, DO NOT WEAR IT AND DO NOT REMOVE PROTECTIVE STICKERS, REMOVE OR SIZE THE STRAP OR BRACELET. IT IS ALMOST IMPOSSIBLE FOR A WATCH TO BE WORN, EVEN FOR A SHORT PERIOD OF TIME, AND NOT BE BLEMISHED OR SCRATCHED IN ANY WAY. ALL SALES ARE CONSIDERED FINAL SHOULD YOU REMOVE STICKERS, REMOVE OR SIZE THE BRACELET OR STRAP AND START WEARING THE WATCH.



All returns must have a Return Authorization No. (RA #). Please contact us prior to return for RA#. We must receive your return shipment within 7 days (5 business days) after you have been assigned an RA#. This number must be displayed on the outside of the box; this will expedite your return. A return of a watch without our prior authorization or 7 days after the RA # has been assigned will be refused.

1. Please be sure the watch you order is the correct size for you. The dimensions of our watches are stated on the site and we will answer your questions regarding dimensions/size, however we cannot accept returns in case a watch is simply smaller/larger than suitable for your wrist or expected.
2. Do not remove the strap or bracelet, have the bracelet sized (links removed) or the protective stickers removed.
3. All product must be returned with complete original packaging, protective stickers still attached, warranty card, original invoice etc. in new and unused condition
4. All returns will be charged a restocking fee of 25% of invoice and original shipping charges. There are no restocking charges on an exchange for another watch from us as long as the conditions for a return as defined in this section are met.
5. Returns must be shipped via traceable courier, e.g. UPS or FEDEX. Return shipment must be pre-paid and fully insured for the amount you expect credit. Collect shipping will be refused. In case of loss or damages, customer is liable.

We believe that all these conditions are reasonable and fair and quite simple to adhere. If for some reason one or multiple conditions cannot be met, please contact us and we will attempt to help BUT you must contact us **immediately** before the 3-day period expires and receive authorization. You will be notified at the time of purchase, if your order is a special order item and the above policy may not apply. Items not usually in stock or specially ordered from the manufacturer are considered special order items. Their sale is final and no return or exchange can be made unless the merchandise is damaged on arrival. All sales are considered final unless we hear from you within 3 days of receipt of product that you wish to return the merchandise and all conditions for a return (see above) are met.



MarcelloC-watches
8674 Chanhassen Hills Drive N.
Chanhassen, MN 55317
USA

  **(952)949-0315**

 **info@marcelloc-watches.com**